



1. Settle the tap body A on the countertop.
2. Place the rubber washer B to the inlet pipe of the tap body A from underneath the countertop.
3. Fasten the nut C to the inlet pipe below the washer B.
4. Connect the water supply.

